




Support: <http://www.jcmglobal.com/en/contact/default.aspx> **Web-Site:** <http://www.jcmglobal.com>

DBV[®] Series

Banknote Validator (DBV-500)

Integration Guide

Revision A, March 17, 2014



P/N 960-000174R_Rev. A {EDP #233488}
Issue #4104-IGE-01-00

© 2014, JAPAN CASH MACHINE CO., LTD.

REVISION HISTORY			
Rev No.	Date	Reason for Update	Comment
A	3-17-14	Initial Document	

International Compliance

- RoHS Directives or or or or
- UL & c-UL Marks
- CE Mark
- CB Scheme

NOTE: The above listed compliance confirmations are currently being examined for approval or certification.

Copyright © 2014 By JAPAN CASH MACHINE CO., LTD.

This product document (hereinafter referred to as "Manual") is fully covered by legal Copyrights owned by the JAPAN CASH MACHINE CO., LTD. (hereinafter referred to as "JCM") under Japanese laws and other Foreign Countries. This Manual contains many copyrighted, patented or properly registered equipment items manufactured by JCM, that are prohibited and illegal to duplicate, replicate, copy in whole, or in part, without the express authorization by JCM with the following exceptions:

1. When an authorized JCM agency or distributor duplicates the Manual for sales promotion and/or service maintenance of the product, or technical service personnel education as required; and
 2. When an end user duplicates the Manual to maintain operation of the product or operate the product in general.
- JCM retains all rights to amend, alter, change or delete any portion of this Manual in whole, or in part, or add items thereto without notice regarding the product or its related products.

JCM is a registered trademark of JAPAN CASH MACHINE CO., LTD. All other product names mentioned herein may be registered trademarks or trademarks of their respective companies. Furthermore, ™, ® and © are not always mentioned in each case throughout this publication.

DBV® Series

Banknote Validator (DBV-500)

	Page
1 GENERAL INFORMATION	1
Description	1
DBV-500 Unit	1
Model Descriptions	2
Type Descriptions	2
Software Descriptions	2
Precautions	2
User Cautions	3
Installation Cautions	3
Mounting, Dismounting & Transportation	3
Placing Foreign Objects into the Unit	3
Preventive Maintenance	3
Banknote Fitness Requirements	4
Primary Features	4
Component Names	5
2 SPECIFICATIONS	6
Technical Specifications	6
Environmental Specifications	7
Electrical Specifications	7
Structural Specifications	7
3 INSTALLATION	8
Installation Procedure	8
Entire Unit Installation	8
Lock Dimension Reference	8
Lock Installation	8
Plastic Latch Installation	8
Metal Lock Installation	8
Frame Lock Installation	9
DIP Switch Configurations	10
DIP Switch Block 1	10
DIP Switch Block 2	10
4 CONNECTOR PIN ASSIGNMENTS	11
Photo-Coupler Isolation Connector Pin Assignments	11
RS232C Connector Pin Assignment	12
TTL Connector Pin Assignment	13
USB Connector Pin Assignment	14
ID-044 Connector Pin Assignment	15
Download Connector Pin Assignment	16
Option Connector Pin Assignment	16
5 PREVENTIVE MAINTENANCE	17
Retrieving Banknotes	17
Clearing a Banknote Jam	17
Cleaning Procedure	18
Sensor and Roller Cleaning Procedure	18
Sensor and Roller Locations	19
6 STANDARD INTERFACE CIRCUIT SCHEMATICS	21
Standard Interface Circuit Schematics (Continued 1)	22
Standard Interface Circuit Schematics (Continued 2)	23
Standard Interface Circuit Schematics (Continued 3)	24

Table of Contents

	Page
7 OPERATIONAL FLOWCHART	25
Operational Flowchart (Continued 1).....	26
Operational Flowchart (Continued 2).....	27
8 TROUBLESHOOTING.....	28
Introduction	28
Troubleshooting Overview	28
Fault Table Listings	28
Adjustment Error	29
Communication Error	30
LED Indication Conditions	30
LED Flash Error Code Conditions	30
9 UNIT DIMENSIONS	33
Entire Unit Outside Dimensions.....	33
Bezel Type1 Dimensions	34
Bezel Type2 Dimensions	34
DBV-500 Installation/Maintenance Space Requirements	35
10 TECHNICAL CONTACT INFORMATION	36
Americas	36
JCM American.....	36
Europe, Africa, Russia & Middle East	36
JCM Europe GmbH.....	36
UK & Ireland	36
JCM Europe (UK Office).....	36
Asia and Oceania	36
JCM Gold (HK) Ltd.....	36
JAPAN CASH MACHINE CO., LTD (HQ).....	36
11 INDEX	37

DBV® Series

Banknote Validator (DBV-500)

List of Figure

	Page
Figure 1 DBV-500 Unit	1
Figure 2 Precautionary Symbols	2
Figure 3 Unacceptable Banknotes	4
Figure 4 Automatic Centering Mechanism	4
Figure 5 DBV-500 Component Names	5
Figure 6 Thread Studs Location	8
Figure 7 Lock Dimension Reference	8
Figure 8 Plastic Latch Installation 1	8
Figure 9 Plastic Latch Installation 2	8
Figure 10 Metal Lock Installation 1	9
Figure 11 Metal Lock Installation 2	9
Figure 12 Frame Lock Installation 1	9
Figure 13 Frame Lock Installation 2	9
Figure 14 Frame Lock Installation 3	9
Figure 15 Frame Lock Installation 4	9
Figure 16 Frame Lock Installation 5	10
Figure 17 Retrieving Banknotes 1	17
Figure 18 Retrieving Banknotes 2	17
Figure 19 Retrieving Banknotes 3	17
Figure 20 JAM Clear 1	17
Figure 21 JAM Clear 2	17
Figure 22 JAM Clear 3	18
Figure 23 JAM Clear 4	18
Figure 24 JAM Clear 5	18
Figure 25 JAM Clear 6	18
Figure 26 General Cleaning Image	18
Figure 27 DBV-500 Sensor and Roller Cleaning Locations	19
Figure 28 DBV-500 Photo-Coupler Interface Schematic Diagram	21
Figure 29 DBV-500 RS232C Interface Schematic Diagram	22
Figure 30 DBV-500 ID-044 PULSE Interface Schematic Diagram	23
Figure 31 DBV-500 ID-044 SERIAL Interface Schematic Diagram	24
Figure 32 DBV-500 Operational Flowchart (Initializing)	25
Figure 33 DBV-500 Operational Flowchart (Validation)	26
Figure 34 DBV-500 Operational Flowchart (Stacking)	27
Figure 35 DBV-500 Unit Entire Outside Dimensions	33
Figure 36 DBV-500 Bezel Type1 Outside Dimensions	34
Figure 37 DBV-500 Bezel Type2 Outside Dimensions	34
Figure 38 DBV-500 Installation and Maintenance Space Requirement	35

THIS PAGE INTENTIONALLY LEFT BLANK

DBV® Series

Banknote Validator (DBV-500)

List of Table

	Page
Table 1 DBV-500 Model Number Specifications	2
Table 2 DBV-500 Type Number Specifications	2
Table 3 DBV-500 Software Number Specifications	2
Table 4 DBV-500 Technical Specifications	6
Table 5 DBV-500 Environmental Specifications	7
Table 6 DBV-500 Electrical Specifications	7
Table 7 DBV-500 Structural Specifications	7
Table 8 DIP Switch Block 1 Settings	10
Table 9 DIP Switch Block 2 Settings	10
Table 10 DBV-500 Photo-Coupler Isolation Unit Side Connector Pin Assignments .	11
Table 11 DBV-500 Photo-Coupler Interface Pin Assignments	11
Table 12 DBV-500 RS232C Unit Side Connector Pin Assignments	12
Table 13 DBV-500 RS232C Interface Pin Assignments	12
Table 14 DBV-500 TTL Unit Side Connector Pin Assignments	13
Table 15 DBV-500 TTL Interface Pin Assignments	13
Table 16 DBV-500 USB Unit Side Connector Pin Assignments	14
Table 17 DBV-500 USB Interface Pin Assignments	14
Table 18 DBV-500 ID-044 Unit Side Connector Pin Assignments	15
Table 19 DBV-500 ID-044 Interface Pin Assignments	15
Table 20 DBV-500 Download Connector Pin Assignments	16
Table 21 DBV-500 Option Connector Pin Assignments	16
Table 22 DBV-500 Sensor Type Cleaning Methods	19
Table 23 General Fault Conditions	28
Table 24 Adjustment Fault Conditions	29
Table 25 Communication Fault Conditions	30
Table 26 LED Flash Error Codes	30

THIS PAGE INTENTIONALLY LEFT BLANK

DBV® Series

Banknote Validator (DBV-500)

Integration Guide

Revision A

1 GENERAL INFORMATION

Description

This section provides a general overview of the DBV® Series Banknote Validator Unit (DBV-500), pictured in Figure 1. This section is designed to help the user navigate through this guide with ease. It includes the following information:

- DBV-500 Unit
- Model Descriptions
- Type Descriptions
- Software Descriptions
- Precautions
- Primary Features
- Component Names
- Specifications
- Installation
- Connector Pin Assignments
- Preventive Maintenance
- Standard Interface Circuit Schematics

- Operational Flowchart
- Troubleshooting
- Unit Dimensions
- Technical Contact Information

In order to make operating this device and navigating within this manual easier, the following illustrations are used:

- **Safety Instructions** need to be observed in order to protect the operators and the equipment; these are identified with **Bold** text and the following pictographs: 
- **Special Notes** affect the use of the Banknote Validator; these are identified with *italic* text and the following pictograph: 
- **Steps** require the operator to perform specific actions; these are identified with sequential numbers (1, 2, 3, etc.).

DBV-500 Unit



Figure 1 DBV-500 Unit

Model Descriptions

Table 1 lists the product model number descriptions.

Table 1 DBV-500 Model Number Specifications

Nº	Model: DBV - 5 * * - (*) * * (/*)
Nº	(1) (2)(3) (4) (5)
(1)	Model Name
(2)	Validation Sensor 0 = Type A (Standard World Wide) 1 = Type B
(3)	Transport Unit Type 0 = Standard (World Wide/Centering Type)
(4)	Intake Part Unit (Optional) None = Standard F = Auto Feeder Unit G = Shutter Unit
(5)	Stacker Type* SD = Downward Stacking (Standard) SU = Upward Stacking (Standard)

*. When using the SD and the SU Types compatibly depends on the Bezel Type, the Stacker Type is indicated as "SD/SU".

Type Descriptions

Table 2 lists the product type number descriptions.

Table 2 DBV-500 Type Number Specifications

Nº	Model: * * * * * - * * * * * - * * * * *
Nº	(1)(2)(3)(4)(5)(6)(7)(8)(9)(10)(11)(12)(13)
(1)	Cash Box Capacity* 0 = No Cash Box (Transport Unit Specification) S = 500 notes (New Banknote) M = 1000 notes (New Banknote) L = 1400 notes (New Banknote)
(2)	Cash Box Door Lock 0 = No Lock 1 = Free Access Lever 2 = Key Lock without Key 3 = Key Lock with Key
(3)	Cash Box Handle 0 = No Handle (Standard) 1 = Handle Type A
(4)	Cash Box Frame Lock 0 = No Lock 1 = Frame Lock without Key 2 = Frame Lock with Key
(5)	Cash Box Acceptable Banknote Length 0 = 120mm-160mm (Standard) 1 = 120mm-170mm
(6)	Bezel 0 = Without Bezel 1 = Bezel Type A (SD/SU Compatible, CC Shape Bezel, Black, 78mm) 2 = Bezel Type B (SD/SU Compatible, CC Shape Bezel, Black, 71mm) 3 = Bezel Type C (SD Specification, JCM Bezel, Black, 78mm)
(7)	Sleep Mode 0 = No 1 = Yes
(8)	Memory 0 = 32M bit (Standard) 1 = 64M bit

Table 2 DBV-500 Type Number Specifications

Nº	Model: * * * * * - * * * * * - * * * * *
Nº	(1)(2)(3)(4)(5)(6)(7)(8)(9)(10)(11)(12)(13)
(9)	Optional Board 0 = None (Standard)
(10)	External Connection Harness 0 = None 1 = Standard Harness 2 = USB I/F Harness
(11)	External Bracket 0 = None 1 = Type A (CC Installation)
(12)	Reserved
(13)	Reserved

*. The number of stacked Notes depends on the Banknote's condition.

Software Descriptions

Table 3 lists the product type number descriptions.

Table 3 DBV-500 Software Number Specifications

Nº	Software: DBV-500-SD/SU USA - * * * - V * * * *
Nº	(A) (B) (C) (D)
(A)	Software Model Name
(B)	Denomination (Country Code)*
(C)	Interface Protocol Name
(D)	Software Version

*. The Country Code is indicated following the ISO 3166 standard.

Precautions




Figure 2 Precautionary Symbols

Symbols in Figure 2 are defined as follows:

- (Type 1) Do not insert a torn, folded, or wet Banknote; it may cause a jam inside the unit.
- (Type 2) Do not expose the unit to water. The unit contains several precision electronic devices that can be damaged if water or any liquid is sprayed or spilled into the unit.
- (Type 3) Do not install the unit in a dusty environment. Dust may affect/degrade the sensor's performance.

USER CAUTIONS

Careful measures were taken in the design of this product to ensure its quality; however, the following cautions pertain to all users and should be followed for safe operation.

Installation Cautions

The Installation Cautions are defined as follows:

1. This unit is not designed for outdoor installation. Be sure the Host Machine contains enough protection to avoid wet or dusty conditions when installing it in both open-air and indoor spaces.
2. Be sure the Host Machine is designed with careful consideration for retrieving a Banknote and/or clearing a Banknote jam.
3. Be careful not to use excessive outside pressure on the Unit Frame when removing the Cash Box from the Unit.
4. Avoid exposing the Banknote Insertion Slot to direct Sunlight and/or Incandescent Lamp illumination having a Gradient Angle of 15 Degrees or more, and an illumination index of 3000 Lux or less. Insure that the Host Machine is also designed to avoid exposing the Banknote Insertion Slot to direct Sunlight or incandescent light.
5. Do not allow the Validator to endure a range of temperature and humidity beyond the environmental limits specified (See "Environmental Specifications" on page 7).
6. Do not use the Validator in environments that may be subject to extreme temperature changes.
7. Do not use the Validator where it may be exposed to airborne evaporated or sporadic chemicals.
8. Clean and maintain the Validator regularly when located in an excessively smoke filled environment.

Mounting, Dismounting & Transportation

Methods for mounting, dismounting and transporting the unit:

1. Be sure to turn the Power OFF before mounting or removing the Unit from its permanent location. Plugging or unplugging Connector Plugs from their receptacles while the Power is ON may cause damage to the Unit.
2. When installing the Transport Unit, ensure that the Transport Part is properly replaced in its correct original location and will not move forward by pulling.
3. Be sure to carry the Unit by both hands when transporting. Holding the Unit by one hand may cause personal injury if the Unit accidentally becomes disassembled and drops away.
4. Be careful not to use excessive outside pressure on the Unit, or subject it to excessive vibration during transportation.
5. Do not throw or pound hard on the Unit. Improper handling may cause personal injury and/or damage to the equipment.

Placing Foreign Objects into the Unit

Observe the following precautions when placing foreign objects into the Unit:

1. Do not insert anything except Banknotes into the Insertion Slot. Inserting Receipts, Stapled Tickets, Rubber Bands, or Credit Cards into the Unit may damage the Banknote Transport path.
2. Do not inject liquids into the Banknote Insertion Slot. Injecting water, oil or cleaning agents may damage the Sensors within the Banknote Transport path.

Preventive Maintenance

The preventive maintenance requirements are defined as follows:

1. When closing the Upper Tray of the Validator, ensure that it clicks firmly into place.



Caution: Be careful to avoid personal injury to your fingers when closing the Upper Guide Section.

2. Do not redesign or disassemble the DBV-500 Validator. Unauthorized use by inadequately trained personnel, or use outside the original manufacturer's intent for operation voids the warranty.



WARNING: Do not inject water or liquid agents of any kind into the Validator, as this may cause extreme damage to the Unit.

3. Perform routine cleaning and maintenance at least once a month to keep the DBV-500 Unit's performance stable.
4. Use a soft, lint-free cloth, cotton swab or compressed air spray to clean dust and debris from the Rollers.



WARNING: To minimize risk of damage to internal printed circuit boards, never allow excess fluid (e.g., from a wet cleaning cloth) to drip or leak into the device. Internal printed circuit boards may be damaged. Do not use any alcohol, citrus based cleaners, solvents or scouring agents that can damage the plastic surfaces of the device.

5. If the Unit is exposed to water or liquids, use a clean, dry micro-fiber cloth to wipe off and absorb excess liquids immediately. Any remaining liquids may affect and degrade the Sensors and Validation component performance.



Caution: Make sure Interface Harness connections to the Host Machine are shorter than 9.84 Feet (3 Meters) in length. Cut off all unused portions of the Interface Harness wiring to avoid static electrical effects or short circuit possibilities that could cause damage to the Unit.



WARNING: This Unit is designed for use with a Current limiting Power Source! Design the Host Cabinet space to meet all local related safety standards.

BANKNOTE FITNESS REQUIREMENTS

The following Banknote types may not validate correctly, or worse, can cause a jam and/or damage to the unit's Transport Path. Banknotes exhibiting the following conditions illustrated in Figure 3 should be avoided:

- torn
- excessive folds or wrinkles
- dirty
- curled
- wet
- containing foreign objects and/or oil




Figure 3 Unacceptable Banknotes

Primary Features

This DBV-500 Series Banknote Validator Unit contains the following primary features:

- **Automatic Centering** – The Centering Mechanism (Figure 4) allows the unit to read Banknotes without using special Banknote Guides. It improves the overall acceptance rate.
- **High-Speed Processing** – The validation processing speed is less than two seconds by the precision high performance validation sensors.




Figure 4 Automatic Centering Mechanism

Component Names

Figure 5 illustrates the DBV-500 component names and locations.




Figure 5 DBV-500 Component Names

2 SPECIFICATIONS

Technical Specifications

Table 4 DBV-500 Technical Specifications

Acceptance Rate [*] :	98% or greater The following banknote types are excluded: <ul style="list-style-type: none">• Banknotes with excess or poor magnetism or unclear graphics• Double (dual) Notes• Worn, dirty, wet, stained, torn or excessively wrinkled Banknotes• Banknotes having folded corners or edges• Banknotes having the wrong cut dimensions or printing displacement• Returned Banknotes because of incorrect or failed insertion.
Banknote Types Accepted:	<ul style="list-style-type: none">• Long side: 120-160mm (4.72-6.29 in.) 120-177mm (4.72-6.97 in.) (Option)• Short side: 60-78mm (2.36-3.07 in.)
Insertion Direction:	Four-Way [†]
Processing Speed [‡] :	Less than 2 seconds (from Banknote insertion to next Banknote insertion)
Validation Method:	Optical Sensor (Transmissive/Reflection) and Magnetic Sensor ^{**}
Diagnostic Indicators:	Bezel Insertion Slot Display: Full-Color + Light Amount DA Control
Escrow:	1 Note
Anti-stringing Mechanism:	Optical Detection and Internal Cash Box Lever
Cash Box Capacity ^{††} :	Approximately 500 notes (new Banknotes) Approximately 1000 notes (new Banknotes) Approximately 1400 notes (new Banknotes)
Cash Box Access:	Rear Access
Interface ^{‡‡} :	Photo-Coupler Isolation [MDB] TTL [ID-003, ID-044, CCNET] RS232C [ID-003, CCNET] USB [ID-008]

*. Refer to the specific Country's "Software Information Sheet" for each Country's particular Banknote acceptance rate.

†. Refer to the specific Country's "Software Information Sheet" for each Country's particular Banknote insertion direction.

‡. Excluding Host Communication time lag (Power Supply: +12V DC, Temperature: 25° C ±5° C, Humidity: 30%-60%).

**.The Magnetic Sensor method depends on the Model.

††.The number of Notes stacked depends on the Banknote's condition.


‡‡.The Interface Harness connecting to the Host should be less than 3m(9.84 ft).

Environmental Specifications

Table 5 DBV-500 Environmental Specifications

Operating Temperature:	-15°C to +60°C (5°F to 140°F) [*]
Storage Temperature:	-20°C to +60°C (-4°F to 140°F) [*]
Relative Operating Humidity:	15% to 90% RH (non-condensed)
Relative Storage Humidity:	15% to 90% RH (non-condensed)
Visible Light Sensitivity:	Avoid contact with direct sunlight (Interior lighting must be incandescent with a Radiant Angle of 15 Degrees or more having an Illumination index of 3000 Lux or less)
Installation:	Indoors Only

*. Depends on hydrothermal conditions.



Electrical Specifications

Table 6 DBV-500 Electrical Specifications

Supply Voltage [*] :	12V DC ±5% (Greater than 2.5A/40W) 24V DC ±5% (Greater than 1.6A/40W)
Current Consumption:	12V DC <ul style="list-style-type: none"> Standby = 312mA Operation = 1.1A Peak = 2.0A 24V DC <ul style="list-style-type: none"> Standby = 184mA Operation = 0.5A Peak = 1.3A Sleep Mode <ul style="list-style-type: none"> Mode A = 40µA (Typ) Mode B = 150µA (Typ)

*. Use a Current Source Limiting Power Supply

Structural Specifications

Table 7 DBV-500 Structural Specifications

Weight:	Unit with Bezel: Approximately 1.4kg (3.09lbs.) 500 notes Cash Box: Approximately 0.8kg (1.76lbs.) 1000 notes Cash Box: Approximately 1.0kg (2.20lbs.) 1400 notes Cash Box: Approximately 1.2kg (2.64lbs.)
Mounting:	Horizontal
Outside Dimensions:	See "Entire Unit Outside Dimensions" on page 33 of this Manual

3 INSTALLATION

This section provides installation and operating instructions for the DBV-500 Banknote Validator unit. The information within this section contains the following features:

- Installation Procedure
- Lock Installation
- DIP Switch Configurations

Installation Procedure

The DBV-500 Frame Unit provides installation grooves for each surface.

ENTIRE UNIT INSTALLATION

Perform the following steps to install the DBV-500 Series Unit:

1. Place the DBV-500 Unit Frame cut outs (Figure 6 a₁ through a₄) on to the Threaded Studs on the chassis.
2. Secure the rear side of the DBV-500 Frame to the chassis with four (4) nuts.




Figure 6 Thread Studs Location

LOCK DIMENSION REFERENCE




Figure 7 Lock Dimension Reference

Lock Installation

There are two (2) Cash Box Locks and single (1) Frame Lock available for securing the DBV-500.

PLASTIC LATCH INSTALLATION

To install the Plastic Latch to the DBV-500 Cash Box, perform the following steps:

1. Place the Door Lock A (Figure 8 a) from the front side of the lock installation hole.
2. Install the Door Lock B (Figure 8 b) from the inside of the lock installation hole while confirming that the Door Lock A Tab is in the vertical direction.




Figure 8 Plastic Latch Installation 1

3. Retain the Door Lock A and the Door Lock B by the single (1) 2.6x8 Phillips, Self-Tapping, Binding Head Screw (Figure 9 a).





Figure 9 Plastic Latch Installation 2


METAL LOCK INSTALLATION

To install the Metal Lock to the DBV-500 Cash Box, perform following steps:

1. Place the Cylinder (Figure 10 a) from the front side of the lock installation hole.
2. Install the Cylinder attachments (Figure 10 b₁ & b₂) and the Door Lock Tang (Figure 10 c) from the inside of the lock installation hole while confirming that the Cylinder direction is correct.

**Figure 10** Metal Lock Installation 1


3. Retain the Cylinder and the Door Lock Tang by the single (1) Screw provided with the Cylinder (Figure 11 a).

**Figure 11** Metal Lock Installation 2


FRAME LOCK INSTALLATION

To install the Frame Lock to the DBV-500 Cash Box, perform following steps:


1. Place the Cylinder (Figure 12 a) from the front side of the lock installation hole.
2. Install the Cylinder attachments (Figure 12 b₁ & b₂) and the Door Lock Tang (Figure 12 c) from the inside of the lock installation hole while confirming that the Cylinder direction is correct.

**Figure 12** Frame Lock Installation 1


3. Retain the Cylinder and the Door Lock Tang by the single (1) Screw provided with the Cylinder (Figure 13 a).

**Figure 13** Frame Lock Installation 2

4. Place the Frame Lock assembly on the rear side of the Cash Box. Be sure that the both sides of the Frame Lock Tabs are inserted to the Tab holes of the Cash Box (Figure 14).

**Figure 14** Frame Lock Installation 3

5. Slide the Frame Lock assembly down to firmly latch it on to the Cash Box (Figure 15).

**Figure 15** Frame Lock Installation 4

6. Retain the Frame Lock assembly to the Cash Box by the single (1) Blind Revet (Figure 16 a) with the $\phi 10$ Washer (Figure 16 b).




Figure 16 Frame Lock Installation 5

DIP Switch Configurations

This section provides the DIP Switch Block 1 (DS1) and 2 (DS2) Settings for the DBV-500 Unit.

DIP SWITCH BLOCK 1

DIP Switch Block 1 is used for setting the acceptable denominations.

Table 8 DIP Switch Block 1 Settings

		ON	OFF	DS1
Switch No.	Switch ON	Switch OFF		
1	VEND 1 INHIBIT	VEND 1 ACCEPT		
2	VEND 2 INHIBIT	VEND 2 ACCEPT		
3	VEND 3 INHIBIT	VEND 3 ACCEPT		
4	VEND 4 INHIBIT	VEND 4 ACCEPT		
5	VEND 5 INHIBIT	VEND 5 ACCEPT		
6	VEND 6 INHIBIT	VEND 6 ACCEPT		
7	VEND 7 INHIBIT	VEND 7 ACCEPT		
8	OFF	OFF		

DIP SWITCH BLOCK 2

DIP Switch Block 2 is used for setting the functions.

Table 9 DIP Switch Block 2 Settings

		ON	OFF	DS2
Switch No.	Switch ON	Switch OFF		
1	-	OFF		
2	-	OFF		
3	-	OFF		
4	-	OFF		
5	-	OFF		
6	-	OFF		
7	-	OFF		
8	-	OFF		


4 CONNECTOR PIN ASSIGNMENTS

Table 10 through Table 21 list the DBV-500 Unit's pin assignments.

PHOTO-COUPLER ISOLATION CONNECTOR PIN ASSIGNMENTS

Table 10 lists the DBV-500 Photo-Coupler Isolation Unit Side Connector Pin Assignments.

Table 10 DBV-500 Photo-Coupler Isolation Unit Side Connector Pin Assignments


				Power Source: MDB Connector Connector (Transport Unit Side): 74164-0006 (MOLEX)			
Pin No.	Signal Name	I/O*	Function				
1	+12V/+24V	-	+12V/24V DC Power Supply				
2	GND	-	Power Ground (0V DC)				
3	WAKEUP0	I/O	Wake Up Signal Line (+5V to 12V) [†]				
4	MASTER RECEIVE	O	Output Signal Line from Validator to Controller				
5	MASTER TRANSMIT	I	Output Signal Line from Controller to Validator				
6	COMMON		Signal Ground				

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

†. No connection when the Pin #3 is not used.

Table 11 lists the DBV-500 Photo-Coupler Interface Pin Assignments.

Table 11 DBV-500 Photo-Coupler Interface Pin Assignments*

																				CN12 Interface Connector Connector (Transport Unit Side): 5-103166-7 (TycoAMP)		
Pin No.	Signal Name	I/O [†]	Function																			
1-18	NC	-	No Connection																			


*. Interface Setting by DIP Switch is required.

†. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

RS232C CONNECTOR PIN ASSIGNMENT

Table 12 lists the DBV-500 RS232C Unit Side Connector Pin Assignments.


Table 12 DBV-500 RS232C Unit Side Connector Pin Assignments

		Power Source: MDB Connector Connector (Transport Unit Side): 74164-0006 (MOLEX)	
Pin No.	Signal Name	I/O*	Function
1	+12V/+24V	-	+12V/24V DC Power Supply
2	GND	-	Power Ground (0V DC)
3	NC	-	No Connection
4	NC	-	No Connection
5	NC	-	No Connection
6	NC	-	No Connection

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

Table 13 lists the DBV-500 RS232C Interface Pin Assignments.

Table 13 DBV-500 RS232C Interface Pin Assignments*

		CN12 Interface Connector Connector (Transport Unit Side): 5-103166-7 (TycoAMP)	
Pin No.	Signal Name	I/O†	Function
1	NC	-	No Connection
2	NC	-	No Connection
3	NC	-	No Connection
4	GND (I/F)	-	Signal Ground (0V DC)
5	NC	-	No Connection
6	NC	-	No Connection
7	NC	-	No Connection
8	NC	-	No Connection
9	NC	-	No Connection
10	NC	-	No Connection
11	NC	-	No Connection
12	NC	-	No Connection
13	NC	-	No Connection
14	NC	-	No Connection
15	RXD (RS232C)	I	Serial Communication Input Signal Line
16	NC	-	No Connection
17	TXD (RS232C)	O	Serial Communication Output Signal Line
18	NC	-	No Connection


*. Interface Setting by DIP Switch is required.

†. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

TTL CONNECTOR PIN ASSIGNMENT

Table 14 lists the DBV-500 TTL Unit Side Connector Pin Assignments.


Table 14 DBV-500 TTL Unit Side Connector Pin Assignments

		Power Source: MDB Connector Connector (Transport Unit Side): 74164-0006 (MOLEX)	
Pin No.	Signal Name	I/O*	Function
1	+12V/+24V	-	+12V/24V DC Power Supply
2	GND	-	Power Ground (0V DC)
3	NC	-	No Connection
4	NC	-	No Connection
5	NC	-	No Connection
6	NC	-	No Connection

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

Table 15 lists the DBV-500 TTL Interface Pin Assignments.

Table 15 DBV-500 TTL Interface Pin Assignments*

		CN12 Interface Connector Connector (Transport Unit Side): 5-103166-7 (TycoAMP)	
Pin No.	Signal Name	I/O†	Function
1	NC	-	No Connection
2	NC	-	No Connection
3	NC	-	No Connection
4	GND (I/F)	-	Signal Ground (0V DC)
5	NC	-	No Connection
6	NC	-	No Connection
7	NC	-	No Connection
8	NC	-	No Connection
9	NC	-	No Connection
10	NC	-	No Connection
11	RXD (TTL)	O	Serial Communication Output Signal Line (+5V)
12	NC	-	No Connection
13	NC	-	No Connection
14	NC	-	No Connection
15	NC	-	No Connection
16	TXD (TTL)	I	Serial Communication Input Signal Line (+5V)
17	NC	-	No Connection
18	NC	-	No Connection


*. Interface Setting by DIP Switch is required.

†. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

USB CONNECTOR PIN ASSIGNMENT

Table 16 lists the DBV-500 USB Unit Side Connector Pin Assignments.


Table 16 DBV-500 USB Unit Side Connector Pin Assignments

		Power Source: MDB Connector Connector (Transport Unit Side): 74164-0006 (MOLEX)	
Pin No.	Signal Name	I/O*	Function
1	+12V/+24V	-	+12V/24V DC Power Supply
2	GND	-	Power Ground (0V DC)
3	NC	-	No Connection
4	NC	-	No Connection
5	NC	-	No Connection
6	NC	-	No Connection

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

Table 17 lists the DBV-500 USB Interface Pin Assignments.

Table 17 DBV-500 USB Interface Pin Assignments*

		CN12 Interface Connector Connector (Transport Unit Side): 5-103166-7 (TycoAMP)	
Pin No.	Signal Name	I/O†	Function
1	NC	-	No Connection
2	NC	-	No Connection
3	NC	-	No Connection
4	NC	-	No Connection
5	NC	-	No Connection
6	VBUS	-	USB Communication VBUS Signal Line (+5V)
7	USBDM	I/O	USB Communication Input/Output Signal Line
8	USBDP	I/O	USB Communication Input/Output Signal Line
9	GND	-	USB Communication Ground (0V DC)
10	NC	-	No Connection
11	NC	-	No Connection
12	NC	-	No Connection
13	NC	-	No Connection
14	NC	-	No Connection
15	NC	-	No Connection
16	NC	-	No Connection
17	NC	-	No Connection
18	NC	-	No Connection


*. Interface Setting by DIP Switch is required.

†. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

ID-044 CONNECTOR PIN ASSIGNMENT

Table 18 lists the DBV-500 ID-044 Unit Side Connector Pin Assignments.


Table 18 DBV-500 ID-044 Unit Side Connector Pin Assignments

		 Power Source: MDB Connector Connector (Transport Unit Side): 74164-0006 (MOLEX)		
Pin No.	Signal Name	I/O*	Function	
1	+12V/+24V	-	+12V/24V DC Power Supply	
2	GND	-	Power Ground (0V DC)	
3	NC	-	No Connection	
4	NC	-	No Connection	
5	NC	-	No Connection	
6	NC	-	No Connection	

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

Table 19 lists the DBV-500 ID-044 Interface Pin Assignments.

Table 19 DBV-500 ID-044 Interface Pin Assignments*

		 CN12 Interface Connector Connector (Transport Unit Side): 5-103166-7 (TycoAMP)															
Pin No.	Signal Name	I/O†	Function														
1	NC	-	No Connection														
2	RTS/FULL	O	Serial Communication Output Signal Line (+5V)														
3	NC	-	No Connection														
4	GND (I/F)	-	Signal Ground (0V DC)														
5	NC	-	No Connection														
6	NC	-	No Connection														
7	NC	-	No Connection														
8	NC	-	No Connection														
9	NC	-	No Connection														
10	ABN	O	Serial Communication Output Signal Line (+5V)														
11	/DATA, /VEND	O	Serial and Pulse Communication Output Signal Line (+5V)														
12	D/E	I	Serial and Pulse Communication Input Signal Line (+5V)														
13	LED-POWER	-	LED Power														
14	NC	-	No Connection														
15	/BUSY	O	Serial Communication Output Signal Line (+5V)														
16	/CTS	I	Serial Communication Input Signal Line (+5V)														
17	NC	-	No Connection														
18	SOFT-R	I	Serial Communication Input Signal Line (+5V)														

*. Interface Setting by DIP Switch is required.

†. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

DOWNLOAD CONNECTOR PIN ASSIGNMENT

Table 20 lists the DBV-500 Download Connector Pin Assignments.

Table 20 DBV-500 Download Connector Pin Assignments

CN4 Connector (Transport Unit Side) USB Mini-B Connector for Download 000011211-00010 (MAIN SUPER)			
Pin No.	Signal Name	I/O*	Function
1	USBo_VBUS	-	VBUS Signal Line (+5V)
2	USBo_DM	I/O	USB Communication Input/Output Signal Line
3	USBo_DP	I/O	USB Communication Input/Output Signal Line
4	NC	-	No Connection
5	GND	-	USB Communication Ground (0V DC)

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

OPTION CONNECTOR PIN ASSIGNMENT

Table 21 lists the DBV-500 Option Connector Pin Assignments.

Table 21 DBV-500 Option Connector Pin Assignments

CN2 Connector (Transport Unit Side) Option Connector B10B-ZR-3.4 (JST)			
Pin No.	Signal Name	I/O*	Function
1	NC	-	No Connection
2	NC	-	No Connection
3	NC	-	No Connection
4	NC	-	No Connection
5	NC	-	No Connection
6	NC	-	No Connection
7	NC	-	No Connection
8	NC	-	No Connection
9	NC	-	No Connection
10	NC	-	No Connection

*. I/O (input/output) is the terminal as viewed from the Banknote Validator's backside.

5 PREVENTIVE MAINTENANCE

Retrieving Banknotes

To retrieve Cash Box deposited Banknotes, perform the following steps:

1. Press the Cash Box Latches (Figure 17 a) located on both sides of the Cash Box and pull the Cash Box out in the direction indicated by the Red arrow.




Figure 17 Retrieving Banknotes 1

2. Rotate the Plastic Latch or the Metal Lock clockwise until in the “OPEN” position and the lock releases (Figure 18).




Figure 18 Retrieving Banknotes 2

3. Open the Cash Box Door (Figure 19 a) and retrieve the Banknotes.




Figure 19 Retrieving Banknotes 3

Clearing a Banknote Jam

To retrieve a jammed Banknote located inside the Banknote Validator, proceed as follows:

1. Press the Unit Guide Open/Close Latches (Figure 20 a).




Figure 20 JAM Clear 1

2. Rotate the entire Upper Tray in the direction indicated by the red arrow A (Figure 21).

NOTE: The Upper Tray can be rotated open to 75° maximum when the Cash Box is seated.






Figure 21 JAM Clear 2

3. When a jammed Banknote is not visible, grab the Cash Box Latches (Figure 22 a) located on both sides of the rear Cash Box and pull the Cash Box out of the Frame Housing.


**Figure 22 JAM Clear 3**

4. Press the Unit Guide Open/Close Latches and rotate entire Upper Tray in direction indicated by the red arrow A (Figure 23).


NOTE: The Upper Tray can be rotated open to 178° maximum after removing the Cash Box.

**Figure 23 JAM Clear 4**

5. When a jammed Banknote is not visible, rotate the Plastic Latch or the Metal Lock clockwise until in the "OPEN" position and the lock releases (Figure 24).

**Figure 24 JAM Clear 5**

6. Open the Cash Box Door (Figure 25 a) and remove a jammed Banknote.

**Figure 25 JAM Clear 6**

Cleaning Procedure

To clean the DBV-500 Validation Section, gently rub the Sensors and Rollers clean using a dry, soft, lint-free, Micro-fiber Cloth ONLY.


Do not use any Alcohol, solvents, Citrus based products or scouring agents that may cause damage to the Validation Section Sensors and/or Rollers.

SENSOR AND ROLLER CLEANING PROCEDURE

To clean the DBV-500 Unit's Sensors and Rollers, proceed as follows:

1. Turn the power **OFF** on both DBV-500 and the Host Machine.
2. Open the DBV-500 Units Front and Rear Guide.
3. Clean the appropriate path and Lens of each Sensor.

Caution: Do not use Alcohol, thinner or Citrus based products for cleaning any Banknote transport Sensors or surfaces. The lenses can become clouded by chemical evaporation residue that may cause acceptance errors.

**Figure 26 General Cleaning Image**

NOTE: Calibration is recommended after cleaning.

SENSOR AND ROLLER LOCATIONS

Figure 27 illustrates the various DBV-500 Unit's sensor and roller cleaning locations. Table 22 lists the DBV-500 sensor type cleaning methods.




Figure 27 DBV-500 Sensor and Roller Cleaning Locations

Table 22 DBV-500 Sensor Type Cleaning Methods

Sym.	Sensor/Roller Type	Cleaning Method
a	Entrance Sensor	Wipe clean using a soft lint-free cloth or blow clean using compressed air.
b	Centering Start Sensor	
c	Side Sensor	
d	COB Sensor	
e	Exit Sensor	

THIS PAGE INTENTIONALLY LEFT BLANK

6 STANDARD INTERFACE CIRCUIT SCHEMATICS

Figure 28 illustrates the DBV-500 Photo-Coupler Interface Schematic Diagram.





Figure 28 DBV-500 Photo-Coupler Interface Schematic Diagram

STANDARD INTERFACE CIRCUIT SCHEMATICS (CONTINUED 1)

Figure 29 illustrates the DBV-500 RS232C Interface Schematic Diagram.

Controller Side



Validator Side




Figure 29 DBV-500 RS232C Interface Schematic Diagram

STANDARD INTERFACE CIRCUIT SCHEMATICS (CONTINUED 2)

Figure 30 illustrates the DBV-500 ID-044 PULSE Interface Schematic Diagram.




Figure 30 DBV-500 ID-044 PULSE Interface Schematic Diagram

STANDARD INTERFACE CIRCUIT SCHEMATICS (CONTINUED 3)

Figure 31 illustrates the DBV-500 ID-044 SERIAL Interface Schematic Diagram.




Figure 31 DBV-500 ID-044 SERIAL Interface Schematic Diagram

7 OPERATIONAL FLOWCHART

Figure 32 depicts DBV-500 Initialization Banknote acceptance flow process.




Figure 32 DBV-500 Operational Flowchart (Initializing)

Operational Flowchart (Continued 1)

Figure 33 depicts DBV-500 Validation Banknote acceptance flow process.




Figure 33 DBV-500 Operational Flowchart (Validation)

Operational Flowchart (Continued 2)

Figure 34 depicts DBV-500 Stacking Banknote acceptance flow process.




Figure 34 DBV-500 Operational Flowchart (Stacking)

8 TROUBLESHOOTING

This section provides troubleshooting instructions for the DBV-500 Banknote Validator Units, including the following information:

- Introduction
- Troubleshooting Overview
- Fault Table Listings
- LED Indication Conditions

Introduction

Most Banknote Validator failures result from minor causes. Before replacing any parts, be sure that all assembly and circuit board connectors are properly fitted with their harnesses properly connected.

Poor performance by the DBV-500 Banknote Validator is often caused when dust or foreign objects adhere to the sensors or rollers. Clean the Banknote validation section first, then carefully observe the operating state of the Validator when re-initializing power. This observation is important

in locating any causes of failure and the possible fault location.

Perform all repairs by referring to Calibration and Testing in Section 6 of the DBV-500 Service Manual, and the Disassembly/Reassembly instructions in Section 4 of the DBV-500 Service Manual.

Troubleshooting Overview

This product allows the operator to perform fault diagnosis by checking various Fault Table Listings against the symptoms. Survey the cause(s) of any failure occurrences during the process.

After determining the cause of the failure, execute the Performance Test, and then repair the unit replacing any appropriate parts deemed necessary.

Fault Table Listings

Table 23, Table 24 and Table 25 list the various possible DBV-500 Unit fault conditions that can occur and the necessary actions required to correct them.

Table 23 General Fault Conditions

Symptoms/Error Messages	Possible Fault Causes	Corrective Action Required
Banknote Validator is not working (does not accept any Banknotes)	No external Power is applied to the Banknote Validator (+12/24V DC & GND)	Verify that the Power Supply +12/24V DC and Ground Cables are connected to their appropriate Pins on the main connector. NOTE: The small LED to the left of the Front Panel DIP Switches indicates power available when lit.
	Wrong or inappropriate connections	Verify that all Harness Connectors are properly connected. Check for any bent, missing or damaged Pins in the Connector Plugs and mating Receptacles.
	Corrupted Software	Re-download the correct Software.
	CPU Board failure	Conduct an Initial Performance Test. If the test result is Negative (NG), replace the CPU Board. Make sure to re-calibrate the Sensors after CPU Board is replaced.
Banknote jams occur often	A Pressure Roller is dirty or damaged	Clean all Pressure Rollers. Replace as necessary.
	A pressure Roller Spring is loose or missing	Check all Pressure Roller Springs using a finger pressure test. Replace as necessary.
	A foreign object is lodged in the Transport path and/or inside the Cash Box	Clean the Transport path and remove any foreign object discovered.
	The Validator Unit is not properly seated all the way into the Frame (the Validator Unit's Latch Release Levers are not locked onto the Frame)	Re-seat the Validator Unit back into the Frame so it is firmly seated. Ensure the Validator Unit Release Lever Latches lock securely onto the Frame.
	The Banknote width is out of specification (Banknote is wider than 78 mm or narrower than 60mm)	Use only Banknotes widths having the correct DBV-500 Unit's size specifications.
Acceptance rates	Dirt and/or stains on the Rollers and Lenses	Clean the Transport path. Refer to "Sensor and Roller Cleaning Procedure" on page 18.
	The Unit has been disassembled, and calibration adjustments have not occurred following a reassembly	Re-calibrate the Sensors after reassembling the DBV-500 Unit.
	The wrong Software version or an older Software version is being used	Make sure that the programmed Software is the latest version, and it supports the Currency values for the specific Country (e.g., check denomination/issuing year).

Table 23 General Fault Conditions (Continued)

Symptoms/Error Messages	Possible Fault Causes	Corrective Action Required
Acceptance rates	Software not designed to accept current Banknotes	Check the particular specifications for the required Banknote Type Acceptance, and make sure the Banknotes will be accepted by the Software loaded (e.g., check denomination/issuing year).
Upper Guide can not be opened	Centering Guides are not at the Home position	Turn the Power OFF and ON again. This action should tell the Host Machine to send a Reset Command to re-initialize the Unit. If power cannot be applied, use a Hexagonal Nut Driver to open the Upper Guide, and manually reset the Guide.
All Banknotes being rejected	Incorrect software (different Currency type) Banknotes are not being accepted by the Software Incorrect DIP Switch settings Banknote acceptance is being inhibited by a Host Controller command Validation Sensor failure Unit was disassembled and calibration was not performed following reassembly	Download the correct Software for Currency being accepted. Make sure the Banknote values required are included in the Software Specifications (e.g., denominations/issuing year). Enable all denominations by setting all DIP Switches to OFF. Enable Banknote acceptance for the required Host Command. Change the CPU Board and/or Sensor Board and calibrate. Calibrate all Sensors following reassembly.
Motor continues to run	Upper Guide is open A foreign object or a jammed Banknote is stuck in the Transport path Motor Drive failure	Firmly close the Upper Guide. Open the Upper Guide, remove the foreign object or jammed Banknote, and close the Cover. Conduct a Forward/Reverse Motor Rotation Test.
Can not enter the TEST mode	Incorrect DIP Switch settings Dip Switch failure CPU Board failure	Set the DS1 DIP Switch No. 8 to ON, and reapply power to the DBV-500 Unit. See Service Manual regarding the DIP Switch Test, and conduct a DIP Switch TEST to check if the specific DIP Switch Block contains a failure. Exchange the CPU Circuit Board with a known good Circuit Board and calibrate.

Adjustment Error

Table 24 lists the various possible DBV-500 Unit Adjustment fault conditions.

Table 24 Adjustment Fault Conditions

Symptoms/Error Messages	Possible Fault Causes	Corrective Action Required
Can not start the “DBV-500 CalibrationToolFor Maintenance.exe” program by double-clicking on its Icon	PC Operating System (OS) is not compatible The Program Files are corrupted	The current Adjustment program only supports the Windows 2000/XP/Windows 7 Operating Systems. Request the correct programs from JCM.
Communication Error	Wrong or inappropriate connections DBV-500 Switch settings are incorrect DIP Switch failure CPU Board failure	Check the PC Harness connections and the related DBV-500 Interface Connectors for damage. Check for any bent, missing or damaged Pins in the Connector Plugs and/or Receptacles. Reset the DBV-500 DS1 DIP Switches #8 to ON (DIP Switch #1 through #7 settings are not specifically required). Apply power to the DBV-500 Unit. See Service Manual regarding DIP Switch settings and conduct a DIP Switch Test. Exchange the CPU Circuit Board with a known good Circuit Board.
Adjustment Error	Incorrect Reference Paper type Validation Sensor failure	Follow the instructions provided in the “DBV-500 CalibrationToolFor Maintenance.exe” Program and use the correct Reference Paper. Change the CPU Board and Sensor Board.

Communication Error

Table 25 lists the various possible DBV-500 Unit Communication fault conditions.

Table 25 Communication Fault Conditions

Symptoms/Error Messages	Possible Fault Causes	Corrective Action Required
Cannot communicate with the Host Machine	DIP Switch settings are incorrect	Set all DIP Switches to OFF.
	Connectors are off or loosely connected	Firmly connect all of the Communication Connectors.
	Damaged Connector Pins	Check for any bent, missing or damaged Pins in the Connector Plugs and mating Receptacles.
	CPU Board is corrupted	Exchange the CPU Circuit Board with a known good Circuit Board.
	Incorrect Interface	Verify that the correct interface between the Host Machine and the Banknote Validator is being used.

LED Indication Conditions

The External LED Display indicates various combinations of solid or alternating Color light flashing conditions when any of the Standard Errors listed in Table 26 occur.

Identify the cause and solution for an indicated error by comparing it against each listing in Table 26.



NOTE: The Error Codes flash different patterns when in the normal operation mode (communicating with the Host Machine) or when performing the Performance Tests. The LED shows more detailed flash patterns while running the performance test to identify the specific error causes.

LED Flash Error Code Conditions

Table 26 lists the various LED Flash Error Code causes & solutions for Banknotes.

Table 26 LED Flash Error Codes

Normal Operation	Performance Test	Error	Causes and Solutions
LED Sequence	LED Sequence		
White (3)	White (1)	External Flash ROM Boot Program ROM Check Error	The Boot Program that is supposed to run after Power is supplied is not correctly written in ROM, or it cannot be read. [Solution] Check that the following part is properly assembled and/or Harness connected. [Relative Parts] CPU Circuit Board. If the error is not resolved, change the above related part or parts and calibrate the unit.
White (3)	White (2)		The Boot Interface Area was not written correctly or cannot be read. [Solution] Re-download the Program. If the error is not resolved, check that the following part is assembled and/or Harness connected. [Relative Parts] CPU Circuit Board. If the error is not resolved, change the above related part or parts and calibrate the unit.
White (3)	White (3)	External Flash ROM Main Program ROM Check Error	The Main Operating Program is not written into the ROM correctly, or cannot be read. [Solution] Re-download the Program. If the error is not resolved, check that the following part is properly assembled and/or Harness connected. [Relative Parts] CPU Circuit Board. If the error is not resolved, change the above related part or parts and calibrate the unit.
White (3)	White (4)	CPU Internal RAM Check Error	RAM reading or writing was not properly performed. [Solution] Check that the following part is properly assembled and/or Harness connected. [Relative Parts] CPU Circuit Board. If the error is not resolved, change the above related part or parts and calibrate the unit.
White (3)	White (4)	External SD-RAM Error	External SD-RAM reading or writing was not properly performed. [Solution] Check that the following part is properly assembled and/or Harness connected. [Relative Parts] CPU Circuit Board. If the error is not resolved, change the above related part or parts and calibrate the unit.

Table 26 LED Flash Error Codes (Continued)

Normal Operation	Performance Test	Error	Causes and Solutions
			LED Sequence
White (3)	White (5)	EEPROM Error	<p>EEPROM reading, writing and/or saving was not properly performed.</p> <p>[Solution] Perform the Sensor Calibration procedure. If the error is not resolved, check that the following part is properly assembled and/or Harness connected. Clean or adjust the following part.</p> <p>[Relative Parts] CPU Circuit Board.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
White (3)	White (6)	Downloading File Error	<p>Downloading files does not proceed.</p> <p>[Solution] Select a file supported by the DBV-500 Unit.</p>
White (3)	White (7)	Magnetic Sensor Setting Abnormal	<p>An abnormal Magnetic Sensor setting is detected.</p> <p>[Solution] Check that the following part is properly assembled and/or Harness connected. Clean the following Sensor.</p> <p>[Relative Parts] Magnetic Sensor.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
White (3)	White (8)	I2C Access Error	<p>While communicating with each device on the CPU Board, Sensors detect an abnormal operating condition.</p> <p>[Solution] Check that the following part is properly assembled and/or Harness connected. Clean the following part.</p> <p>[Relative Parts] Stacker.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
Red (3)	Red (1)	Stacker Motor Lock-Up	<p>While operating the Stacker Motor, no pulse inputs occurred greater than the specified value.</p> <p>[Solution] Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors.</p> <p>[Relative Parts] Stacker Motor, Stacker Encoder.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
Red (3)	Red (2)	Pusher Mechanism Home Position Error	<p>When stacking Banknotes, the Pusher Mechanism is not returning to the Home and position.</p> <p>[Solution] Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors.</p> <p>[Relative Parts] Pusher Mechanism, Stacker Motor, Stacker Home Sensor, Stacker Motor Encoder.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
Red (3)	Red (3)	Banknote Jam (Cash Box)	<p>When transporting a Banknote in the Cash Box, the Sensors are not detecting a Banknote present condition when the time interval is too long, or the pulse number is greater than specified value for the function.</p> <p>[Solution] Remove Banknotes from the Cash Box.</p> <p>Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors.</p> <p>[Relative Parts] Exit Sensor, Pusher Mechanism, Stacker Motor, Stacker Home Sensor, Stacker Motor Encoder.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
Red (3)	Red (4)	Feed Motor Speed Error	<p>While Initializing, no pulse inputs exist greater than the specified value.</p> <p>[Solution] Remove Banknotes from the DBV-500 Unit.</p> <p>Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors.</p> <p>[Relative Parts] Feed Motor, Feed Motor Encoder.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
Red (3)	Red (5)	Feed Motor Lock-Up	<p>While operating the Feed Motor, no pulse inputs occurred greater than the specified value.</p> <p>[Solution] Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors.</p> <p>[Relative Parts] Feed Motor, Feed Motor Encoder.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>
Red (3)	Red (6)	Centering Mechanism Abnormal	<p>The Centering Guide has not moved.</p> <p>[Solution] Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors.</p> <p>[Relative Parts] Centering Guide, Centering Motor, Centering Guide Home Sensor.</p> <p>If the error is not resolved, change the above related part or parts and calibrate the unit.</p>

Table 26 LED Flash Error Codes (Continued)

Normal Operation	Performance Test	Error	Causes and Solutions
LED Sequence	LED Sequence		
Red (3)	Red (7)	Reserved	Contact your local JCM Representative if this error occurs.
Red (3)	Red (8)	Fraud Detection	Sensors detect Banknotes occurring with abnormal timing. [Solution] Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors. [Relative Parts] Entrance Sensor, Centering Timing Sensor, Validation Sensor, PB Entrance Sensor, PB Exit Sensor, Exit Sensor, Feed Motor and Feed Motor Encoder. If the error is not resolved, change the above related part or parts and calibrate the unit.
Purple (3)	Purple (1)	Cash Box Full	Sensors detected that the Cash Box is full. [Solution] Remove Banknotes from the Cash Box. Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors. [Relative Parts] Pusher Mechanism, Stacker Motor, Stacker Home Sensor, Stacker Motor Encoder. If the error is not resolved, change the above related part or parts and calibrate the unit.
Purple (3)	Purple (2)	Cash Box Removal	The Cash Box has been removed. [Solution] Firmly re-seat the Cash Box. Check that the following part is properly assembled and/or Harness connected. Clean or adjust the following Sensor. [Relative Parts] Box Sensor. If the error is not resolved, change the above related part or parts and calibrate the unit.
Purple (3)	Purple (3)	Banknote Jam (Transport Unit)	When transporting or returning a Banknote in the Transport Unit, the Sensors did not detect a Banknote present condition when the time interval was too long, or the pulse number is greater than specified value for the function. [Solution] Check that the following parts are properly assembled and/or Harness connected. Clean or adjust the following parts and Sensors. [Relative Parts] Entrance Sensor, Centering Timing Sensor, Validation Sensor, PB Entrance Sensor, Exit Sensor, Feed Motor, Feed Motor Encoder. If the error is not resolved, change the above related part or parts and calibrate the unit.

9 UNIT DIMENSIONS

ENTIRE UNIT OUTSIDE DIMENSIONS

Figure 35 illustrates the DBV-500 Unit's Entire Outside Dimensions.




Figure 35 DBV-500 Unit Entire Outside Dimensions

BEZEL TYPE1 DIMENSIONS

Figure 36 illustrates the DBV-500 Bezel Type1 Outside Dimensions.




Figure 36 DBV-500 Bezel Type1 Outside Dimensions

BEZEL TYPE2 DIMENSIONS

Figure 37 illustrates the DBV-500 Bezel Type2 Outside Dimensions.




Figure 37 DBV-500 Bezel Type2 Outside Dimensions

DBV-500 Installation/Maintenance Space Requirements

Figure 38 illustrates the DBV-500 installation and maintenance space requirement.




Figure 38 DBV-500 Installation and Maintenance Space Requirement

10 TECHNICAL CONTACT INFORMATION

To obtain further technical information regarding the DBV-500 device, please contact the nearest location listed below:

AMERICAS

JCM American

Phone: +1-702-651-0000
 Fax: +1-702-644-5512
 925 Pilot Road, Las Vegas, NV 89119
 E-mail: support@jcmglobal.com

EUROPE, AFRICA, RUSSIA & MIDDLE EAST

JCM Europe GmbH

Phone: +49-211-530-645-60
 Fax: +49-211-530-645-85
 Muendelheimer Weg 60
 D-40472 Duesseldorf Germany
 E-mail: support@jcmglobal.eu

UK & IRELAND

JCM Europe (UK Office)

Phone: +44 (0) 190-837-7331
 Fax: +44 (0) 190-837-7834
 Unit B, Third Avenue
 Denbigh West Business Park
 Bletchley, Milton Keynes,
 Buckinghamshire MK1 1DH, UK
 E-mail: support@jcmglobal.eu

ASIA AND OCEANIA

JCM Gold (HK) Ltd.

Phone: +852-2429-7187
 Fax: +852-2929-7003
 Unit 1-7, 3/F., Favor Industrial Centre
 2-6 Kin Hong Street, Kwai Chung,
 N.T. Hong Kong
 E-mail: asiapactechsupport@jcmglobal.com

JAPAN CASH MACHINE CO., LTD (HQ)

Phone: +81-6-6703-8400
 Fax: +81-6-6707-0348
 2-3-15, Nishiwaki, Hirano-ku, Osaka 547-0035
 JAPAN
 E-mail: Shohin@jcm-hq.co.jp

All of these Websites are available via:
<http://www.jcmglobal.com>

DBV® Series

Integration Guide

Index

11 INDEX

B

Banknote Jam
 clearing a ...17
Banknote Validator
 general information describing a ...1

C

Cleaning
 methods of, and equipment required for ...18

D

DBV-500
 photo of a ...1

Dimensions
 entire unit clearance
 illustrated drawing for ...33

F

Fault Table
 table listings of ...28
Flowchart
 Operational
 symbol language describing flow functions ...25

I

Installation
 steps required for ...8

M

Model Descriptions
 Product Number Specifications of ...2

N

Navigation
 within manual
 procedure for ...1

P

Pin Assignments
 Table Listing of ...11
Precautionary Symbols
 types of ...2
Primary Features
 DBV-500
 DBV Product Series of ...4

S

Safety
 pictographs indicating
 1 to 3 symbols inside boxed area ...1
Software Descriptions
 Product Number Specifications of ...2
Special Notes
 italic text highlights
 finger points to ...1
Steps
 sequential numbering of ...1

T

Technical Contact Information
 location listing of ...36
Troubleshooting
 Instructions for ...28
Type Descriptions
 Product Number Specifications of ...2

THIS PAGE INTENTIONALLY LEFT BLANK



Issue #4104-IGE-01-00